

EMPIRE®

REVISED
2/12

VBC SERIES AC/DC VIDEO/DIGITAL BATTERY CHARGERS

SPECIAL
100-240V
CHARGER

NOW 100-240V AT THE
SAME LOW PRICE

IDEAL FOR TRAVEL



Our VBC Lithium-Ion Video/Digital Battery Charger is packed with all these great advantages:

- UL with reverse polarity protection, with overheating and overcharge protection
- Consumer friendly – Easy to use – No confusing plates to mount
- Two color LED indicates charging status and full charge
- Deluxe clam packaging with 12V car adapter and 100-240V wall transformer
- Simple numbering system – Charger number matches Empire battery number**
- Most batteries achieve 80% capacity in under 2 hours
- New, smaller footprint takes up less space on your desk or in your camera bag

**Example: The VBC-256P Charger will charge the Empire BLI-256 battery

EMPIRE CENTRAL

1501 Tonne Ave.
Elk Grove Village, IL 60007
Phone: (800) 221-6012
Fax: (800) 719-9902

HEADQUARTERS

P.O. Box 817
151 East Industry Court
Deer Park, NY 11729-5713
Phone: (800) 645-7220
Fax: (800) 343-5733

EMPIRE SOUTH

4504 E. Hillsborough Ave.
Tampa, FL 33610
Phone: (800) 810-8891
Fax: (877) 422-8866

VISIT US ON THE WEB: www.empirescientific.com ● E-MAIL: sales@empirescientific.com

LS21 R7

EMPIRE® VBC Series Video/Digital Battery Chargers

V	VBC-6V/JPS	4.8V/6V NiCd & NiMH JVC, PANASONIC, SONY - ALL CAPACITIES	D	VBC-285P	KODAK KLIC-7002
V	VBC-109P	USE VBC-6V/JPS	D	VBC-286P	KODAK KLIC-7001
V	VBC-150P	USE VBC-6V/JPS	D	VBC-287P	SONY NP-BG-1
D V	VBC-153P	SONY NP-F550,750,950 "L" SIZE	D	VBC-293P	NIKON EN-EL3e
D V	VBC-153/180P	SONY NP-FM30/50/70/90, F330/550/750/950	D	VBC-296P	SAMSUNG SB-LH82
V	VBC-155P	USE VBC-6V/JPS	D	VBC-297P	CANON NB-5L
D V	VBC-156P	SHARP BT-L1/L2/L12/L21	D	VBC-298P	PANASONIC DMW-BCD10/S007E
V	VBC-158P	USE VBC-164P	D	VBC-300P	KODAK KLIC-8000
V	VBC-159P	USE VBC-6V/JPS	D	VBC-304P	NIKON EN-EL9,9A
V	VBC-161P	CANON BP-914,927	D V	VBC-307P	PANASONIC VW-VBG-130K,260K
D V	VBC-162P	JVC BN-V812, PANASONIC AG-BP15	D V	VBC-308P	SONY NP-FH50/70/90
V	VBC-164P	SHARP BT,H22,H32, H42	V	VBC-309P	JVC BN-V808/815/823
V	VBC-166P	HITACHI VMBPL13,27	D	VBC-310P	KODAK KLIC-7003
D V	VBC-172P	PANASONIC CGR-D120,220	D	VBC-315P	VIVITAR 83005, 8330, 8600
V	VBC-175P	JVC BN-V507,514	D	VBC-320P	NIKON EN-EL10
V	VBC-176P	SHARP BT-L221/L241/L441	D	VBC-325P	GE GB-40 (USE VBC-310P)
V	VBC-177P	SHARP BT-L221U (USE VBC-176P)	D	VBC-326P	GE GB-20 (USE VBC-310P)
D V	VBC-180P	SONY NP-FM50,70,90	D	VBC-327P	KODAK KLIC-7006
V	VBC-181P	PANASONIC CGR-V610,620	D	VBC-328P	POLAROID M635 (USE VBC-285P)
V	VBC-182P	JVC BN-V207,214	D	VBC-329P	FUJI NP-50 (USE VBC-285P)
D	VBC-183P	KODAK KLIC3000/FUJI NP80	D	VBC-330P	KODAK KLIC-7004 (USE VBC-285P)
V	VBC-192P	JVC BN-V406,416,428	D	VBC-331P	FUJI NP-45 (USE VBC-272P)
D V	VBC-193P	CANON BP-511,522	D	VBC-333P	PENTAX D-Li68 (USE VBC-285P)
V	VBC-195P	SAMSUNG SB-L160,320,480	D	VBC-334P	SONY NP-BD1 (USE VBC-247P)
D	VBC-198P	CANON NB-1L	V	VBC-335P	SAMSUNG IA-BP85ST
D	VBC-201P	NIKON EN-EL1	D	VBC-337P	CASIO NP-60
D	VBC-203P	FUJI NP-60	V	VBC-338P	CANON BP-807,808,809,819,827
D V	VBC-204P	CANON NB-2L	D	VBC-339P	OLYMPUS Li50B
V	VBC-205P	SHARP BT-L225/L445	D	VBC-341P	SAMSUNG SLB-10A,11A
D	VBC-211P	NIKON EN-EL3	D	VBC-345P	NIKON EN-EL11
V	VBC-214P	SHARP BT-LS222U (USE VBC-176)	D	VBC-348P	CANON NB-6L
D	VBC-216P	CASIO NP-20	D	VBC-350P	CANON LP-E5
D	VBC-222P	SANYO, FUJI NP-40	D	VBC-351P	USE VBC-287P
D	VBC-224P	OLYMPUS LiB10	V	VBC-352P	SAMSUNG IA-BP80W
D	VBC-225P	PANASONIC CGR-S002, DMW-BM7	D	VBC-354P	NIKON EN-EL12
D	VBC-228P	FUJI NP-120, RICOH DB-43	D	VBC-361P	PANASONIC DMW-BLB13/13E/13PP (USE VBC-230P)
V	VBC-229P	SHARP BT-L226U	D	VBC-363P	PENTAX D-Li88, SANYO DB-L80 (USE VBC-287P)
V	VBC-230P	HITACHI DZ-BP07S, PAN.CGA-DU07	D	VBC-364P	PENTAX D-Li92 (USE VBC-287P)
D	VBC-236P	KODAK KLIC-5001	D	VBC-365P	CASIO NP-80 (USE VBC-272P)
D	VBC-239P	NIKON EN-EL5	D	VBC-366P	SAMSUNG SLB-07A (USE VBC-296P)
D	VBC-240P	OLYMPUS BLM-1	D	VBC-367P	PANASONIC DMW-BCF10/10E (USE VBC-368P)
D	VBC-241P	PANASONIC CGA-S302	D	VBC-368P	PANASONIC DMW-BCG10/10E/10PP
V	VBC-246P	SONY NP-FP50/70/90	V	VBC-370P	SAMSUNG SLB-11A (USE VBC-341P)
D	VBC-247P	SONY NP-FT1	V	VBC-376P	CANON BP-808 (USE VBC-338P)
D	VBC-251P	CASIO NP-40	V	VBC-377P	SAMSUNG IA-BP80WA (USE VBC-352P)
D	VBC-253P	SONY NP-FR1	D	VBC-378P	CANON NB-8L (USE VBC-256P)
D	VBC-255P	FUJI NP-30	V	VBC-380P	SONY NP-FV SERIES (USE VBC-308P)
D	VBC-256P	CANON NB-4L	D	VBC-382P	SAMSUNG BP-70A (USE VBC-287P)
D	VBC-259P	MINOLTA NP-700, SANYO DB-L30	D	VBC-383P	CASIO NP-110 (USE VBC-367P)
V	VBC-262P	PANASONIC CGA-D54	D	VBC-384P	CANON LP-E8 (USE VBC-204P)
V	VBC-264P	KYOCERA / CONTAX BP-760S	D	VBC-387P	SANYO DB-L90 (USE VBC-294P)
V	VBC-270P	JVC BN-V707/714/733	D	VBC-391P	PANASONIC DMW-BCH7 (USE VBC-298P)
V	VBC-271P	SAMSUNG SB-LS80/LSM80/LSM160	V	VBC-392P	JVC BN-VG107, VG114, VG121
D	VBC-272P	OLYMPUS Li40B, CASIO NP-82	V	VBC-394P	JVC BN-VF908 (USE VBC-309P)
D	VBC-273P	USE VBC-CRV3 KIT	D	VBC-395P	SONY NP-FW50 (USE VBC-246P)
D V	VBC-276P	KYOCERA/CONTAX BP-1100S	V	VBC-396P	PANASONIC VW-VBD19 (USE VBC-172P)
V	VBC-277P	USE VBC-300P	D	VBC-398P	CANON NB-9L (USE VBC-297P)
D	VBC-283P	PANASONIC DMW-BMA7/S006E			

KEY: **D** Used with Digital Cameras **V** Charges NiMH & NiCd Batteries **V** Used with Video Cameras

In most cases USE information applies to current generation chargers as additions are constantly being made.

VISIT US ON THE WEB: www.empirescientific.com • E-MAIL: sales@empirescientific.com